

MPU011A Assembly Instructions

1. Install either a 6802 or a 6808 uP into the sockets labeled U_3D (on main board) and U24 (on daughter board)
2. Install Game ROMs into sockets labeled U27 and U28 on the main board. Note: U28 is mislabeled, it should be U26
3. Install Sound ROMs into sockets labeled U21 and U22 on the daughter board **Note: These are ROMs from MPU/Driver Board**
4. Install the two white spacers into the top-left and bottom-right mounting holes of the daughter board
5. Carefully attach daughter board to the main board making sure all spacers and connectors align properly. Note connector 1J16 should be at the top of the daughter board

